

TXO20 - Transformer Ohmmeter (20A)

TXO20 - Transformer Ohmmeter (20A)

Rating: Not Rated Yet

[Ask a question about this product](#)

Description

TXO20 - Transformer Ohmmeter (20A)

The DC resistance is the transformer's semi-finished product, finished product test, installation, commissioning test, and electric part prevention test necessary test project, the transformer coil can effectively find the device welding, connecting parts loose, missing unit, disconnection, and other manufacturing default and other hidden danger occurred after operation.

The DC Resistance transformer to meet fast measurement requirement, we developed TXO20 DC Resistance Tester. The instrument is a new powerful technology, small size, light weight, high output current and other characteristics.

The device is controlled by the microcontroller, with a high degree of automation, automatic discharge functions. It is a test instrument of high precision, simple, direct way to achieve fast transformer measurement.

Features

- **Whole instrument controlled by high speed SCM, high automatic degree and simple operation.**

- Has a complete circuit protection, and reliable.
- Discharge alarm, discharge indicator clear, reduces misuse. Quick response speed, can be directly converted to load tap switch at measuring state, the instrument automatically refresh data.
- Intelligent power management technology, instrument is always working at minimum power state, effective energy saving, reduce heat.
- 320 x240 matrix of ultra small pixel 65K true color LCD.
- With calendar clock and power storage, can store 1000 groups data, can be check at any time.
- With RS232 and USB interface, computer communications and U disk storage.



[Transformer Winding Resistance Testing Using TXO20](#)